




Winlink

HOW TO SEND ONCE YOUR SET UP



1. Click on Message
2. Select New Message

Enter a new message

Close Select Template Attachments Post to Outbox Spell Check Save in Drafts

From: W5WK Send as: Winlink Message Request message receipt Set Defaults

To: W5PPR;

Cc:

Subject: Winlink Presentation Email

Attach:

Here is a quick guide to get you started towards setting up a winlink station <https://www.winlink.org/>
Equipment Needed: Radio, Computer and Packet TNC. There are software TNC's available like UZ7HO
<http://uz7.ho.ua/packetradio.htm> for packet. Now, there is another, better option for connecting
using a software called VARA or VARA FM. If you choose either of these options you will need a signal link to
interface between your radio and computer <http://www.tigertronics.com/>. Some radios have built in
sound cards which is a bonus for sure.
User Setup: First download Winlink Express and ensure you have the latest release.
https://downloads.winlink.org/User%20Programs/Winlink_Express_install_1-7-0-0.zip

System Requirements: Microsoft-supported 32 or 64 bit Windows OS (Windows Vista, Windows 7, 8,
10 or Windows 2003 Server, or later, or under Windows on Apple Mac and Linux machines using a VM
engine or dual boot arrangement. Windows XP or earlier OS are not supported. The program makes
minimal CPU demands with the exception of WINMOR operation. The heavy DSP demands of WINMOR
require a computer of at least 700 MHz Pentium/Celeron class and at least 512 Meg of memory. It runs
well on all modern computers and Windows tablets. If multiple applications are running concurrently,
we recommend a fast computer with extra RAM.
You will need to register. How to get an account instruction can be found from the My Account tab at the Winlink
webpage.
Remember this is a use it or lose it account. Accounts off-air for 400 days are automatically purged.
With some quick googling and using winlinks extensive Help library you will be up in no time. There is
not much reason for me to go into deep detail here as I would just be duplicating information that is
already available. Here's a link to the Book of Knowledge
https://www.winlink.org/content/winlink_book_knowledge
Good luck and have fun Tim - W5WK


- New window will open
1. Type in Callsign in field labeled To:
 2. Add Subject
 3. Compose Message
 4. Click Post to Outbox


Once you've clicked post to outbox, the message window will close. You will be back at the main window and ready to send.

You can see here that you have 1 message in Outbox.

5. Now, Select how you would like to connect from the dropdown menu and click. We are choosing Telnet here.


6. Click Open Session:





7. Click Start

That's the basics for sending a Winlink Email!
To check for new messages from others, repeat steps 5 thru 7



```
Telnet Winlink Session
Exit  Settings  Start  Stop  Time to next Autoconnect = Disabled
*** Connecting to a CMS...
*** Connected to CMS-SSL at 2022/09/10 22:29:36
[WL2K-5.0-B2FWIHJM$]
:PQ: 16693674
CMS>
:FW: W5WK
[RMS Express-1.7.0.0-B2FHM$]
:PR: 97227795
:WL2K DE W5WK (EM12HL)
FC EM G8T6RTN1Q6ZQ 2092 1269 0
F> 09
FS Y
*** Sending G8T6RTN1Q6ZQ.
FF
*** Completed send of message G8T6RTN1Q6ZQ
*** Sent 1 message. Bytes: 1314, Time: 00:00, bytes/minute: 579298
FQ
*** -- End of session with WL2K at 2022/09/10 22:29:41 --
*** Messages sent: 1. Total bytes sent: 1314, Time: 00:04, bytes/minute: 16070
*** Messages Received: 0. Total bytes received: 0, Total session time: 00:04, bytes/minute: 0
*** Disconnecting
*** Disconnected at 2022/09/10 22:29:42
```